

RBS AUTO PARTS INTERNATIONAL TRADE CO., LTD

Add: Unit 10, Mezzanine, No. 564, Jiahe Road, Huli District, Xiamen, China
Email: manager@rbsautoparts.com Tel: +86-13222800878



1-53215-039-0 Engine mount engine support for Isuzu V10 V295



1-53215-048-0 Engine mount engine support for Isuzu JCM 6BB1 4BC2



1-53215-061-0 Engine mount engine support for Isuzu V12 V330 340 10PE1 JUMBO 200



1-53215-132-1 Engine mount engine support for Isuzu V12 V330 340 10PE1



1-53366-025-0 1-53366-026-0 Engine mount engine support for Isuzu Jumbo Rocky 175



1-532253-313-0 1-532253-314-0 GEAR BOX MOUNTING FOR ISUZU FSR LH



5-37516-005 Engine mount engine support for Isuzu



5-3459644-0 Engine mount engine support for Isuzu



8-94111-903-0 Engine mount engine support for Isuzu NPR NKR (2)



8-94111-903-GC Engine mount engine support for Isuzu



8-94119-958-1 Engine mount engine support for Isuzu NPR 97 NQR 97



8-94155-652 LEFT Engine mount engine support for Isuzu



8-94241-766-0 Engine mount engine support for Isuzu Faster



8-94375-284-0 Engine mount engine support for Isuzu Pickup RH LH



8-97029-579-0 Engine mount engine support for Isuzu



8-97039-189-2 Engine mount engine support for Isuzu D-MAX TFR 2800 Trooper 4 JG

RBS AUTO PARTS INTERNATIONAL TRADE CO., LTD

Add: Unit 10, Mezzanine, No. 564, Jiahe Road, Huli District, Xiamen, China
Email: manager@rbsautoparts.com Tel: +86-13222800878



8-97079-219-1 Engine mount engine support for Isuzu NPR 4HG1 RH 92MM

8-97079-220-1 Engine mount engine support for Isuzu NPR 120 HP

8-97092-069-0 Engine mount engine support for Isuzu NHR 4BE1 LH

8-97110-036 Engine mount engine support for Isuzu



8-97367-272-0 Engine mount engine support for Isuzu D-MAX 2009 4JJ1 4JA1 4JH1

9-53215-057-0 Engine mount engine support for Isuzu TXD55

9-53215-602-0 Engine mount engine support for Isuzu TLD BLD KS250 C240 ELF250

9-53218-058-0 Engine mount engine support for Isuzu



16-0095A Engine mount engine support for Isuzu Pickup TRF LH

8672 Engine mount engine support for Isuzu

16392-76020 16392-76011 Engine mount engine support for Isuzu TRF

8682 Engine mount engine support for Isuzu



68873 Engine mount engine support for Isuzu

68967 Engine mount engine support for Isuzu

68968 Engine mount engine support for Isuzu

94150-265-2 Engine mount engine support for Isuzu

RBS AUTO PARTS INTERNATIONAL TRADE CO., LTD


Add: Unit 10, Mezzanine, No. 564, Jiahe Road, Huli District, Xiamen, China
Email: manager@rbsautoparts.com Tel: +86-13222800878



3178158697 Engine Mount Front PAIR Set for Isuzu



8-97187-417-0 ENGINE MOUNT FRONT LH FOR ISUZU



8-94111-903-0 ENGINE MOUNT REAR FOR ISUZU NPR



8-94482-405-0 8052 608579 Transmission Engine Motor Mounts Front Left Set 2.3 2.6



A5316 5316 MK5316 Front Right Engine Motor Mount For Isuzu



841257100514 Engine Motor Mount Front Left or Right 2.2 L For Isuzu Pickup L4



6-61333311-4 AUTO RUBBER BUSHING FOR Isuzu



8-94150-265-3 AUTO RUBBER BUSHING FOR Isuzu



8-94226-557-2 AUTO RUBBER BUSHING FOR Isuzu



8-94113314-2 AUTO RUBBER BUSHING FOR Isuzu NPR NKR 1988



8-94118588-1 AUTO RUBBER BUSHING FOR Isuzu NKR 1995 NPR 1995-1997 NPR 120



8-94374448 AUTO RUBBER BUSHING FOR Isuzu



8-94408842 AUTO RUBBER BUSHING FOR Isuzu



8-94433673-0 AUTO RUBBER BUSHING FOR Isuzu TFR

RBS AUTO PARTS INTERNATIONAL TRADE CO., LTD

Add: Unit 10, Mezzanine, No. 564, Jiahe Road, Huli District, Xiamen, China
Email: manager@rbsautoparts.com Tel: +86-13222800878



8-97227996-0 AUTO RUBBER BUSHING FOR Isuzu

9-3351(CBA361) AUTO RUBBER BUSHING FOR Isuzu

9-51351029-0 S250-74 AUTO RUBBER BUSHING FOR Isuzu

9-61351029-1 AUTO RUBBER BUSHING FOR Isuzu Hino



AUTO RUBBER BUSHING FOR Isuzu NKR

9-89445945-9 AUTO RUBBER BUSHING FOR Isuzu KBZ TFR 1980-1986 KBD21



B-97095-149-0 Strut Rubber Engine Mounting for Isuzu

841257138371 Strut Mounts for Isuzu

841257113316 Strut Mount for Isuzu

RS005 STRUT TOP MOUNT PAIR FOR ISUZU D-MAX



932902 strut mount for Isuzu Impulse 90-92

940901 strut mount for Isuzu Oasis 96-99

RBS AUTO PARTS INTERNATIONAL TRADE CO., LTD

Add: Unit 10, Mezzanine, No. 564, Jiahe Road, Huli District, Xiamen, China

Email: manager@rbsautoparts.com Tel: +86-13222800878



**1-37510-105-0 CENTER
BEARING SHAFT BEARING
FOR Isuzu Rocky**

**1-37516-003-1 CENTER
BEARING SHAFT BEARING
FOR Isuzu**

**1-37516-005-1 ID=40MM ID40
CENTER BEARING SHAFT
BEARING FOR Isuzu**

**1-37516-006-1 CENTER
BEARING SHAFT BEARING
FOR Isuzu JCM**



**1-37516-043-1 ID=60mm
CENTER BEARING SHAFT
BEARING FOR Isuzu**

**1-37516-048-1 85mm
CENTER BEARING SHAFT
BEARING FOR Isuzu**

**1-37516-051-1 (P110)
CENTER BEARING SHAFT
BEARING FOR Isuzu**

**1-37516-105-0 CENTER
BEARING SHAFT BEARING
FOR Isuzu 6BD1 FSR113**



**1-53459-231-1 CENTER
BEARING SHAFT BEARING
FOR Isuzu**

**8-94222-972-0 CENTER
BEARING SHAFT BEARING
FOR Isuzu**

**8-94328-799-0 CENTER
BEARING SHAFT BEARING
FOR Isuzu TFR 2500 DI 4WD**

**8-94328-800-0 CENTER
BEARING SHAFT BEARING
FOR Isuzu D-MAX TFR 2500**



**8-97581-250-0 CENTER
BEARING SHAFT BEARING
FOR Isuzu**

**9-37516-030-0 CENTER
BEARING SHAFT BEARING
FOR Isuzu TLD BLD KSC240**

**9-51519-057-0 CENTER
BEARING SHAFT BEARING
FOR Isuzu**

Part Number	Make	Model	Description
1-15449-009-0	ISUZU	V10	FUEL CONNECTOR
1-36189-026-0	ISUZU	JCM	REAR ENGINE MOUNTING
1-37510-045-0	ISUZU	NPR, SBR	PROPELLER SHAFT BEARING
1-37510-092-0	ISUZU	ROCKY 175HP, 240HP	PROPELLER SHAFT BEARING
1-37510-092-2	ISUZU	ROCKY 175HP, 240HP	PROPELLER SHAFT BEARING
1-37510-092-2	ISUZU	ROCKY 240HP	Pro'Shaft Bearing
1-37510-105-0	ISUZU	JCR, SBR, ROCKY	PROPELLER SHAFT BEARING
1-37510-105-0	ISUZU	ROCKY	Pro'Shaft Bearing
1-37516-003-0	ISUZU	10PA/PB1	CENTER BEARING CUSHION
1-37516-005-1	ISUZU	NPR, NKR (63/32)	PROPELLER SHAFT BEARING
1-37516-006-0	ISUZU	KS21, KS22 (6208)	PROPELLER SHAFT BEARING
1-37516-006-1	ISUZU	KS21, KS23	PROPELLER SHAFT BEARING
1-37516-045-0	ISUZU	BUS 260HP, NPR, SBR	PROPELLER SHAFT BEARING
1-37516-045-0	ISUZU	NPR,SBR	Pro'Shaft Bearing
1-48119-081-1	ISUZU	SLK, SMK	BRAKE PAD
1-51519-039-0	ISUZU	TMK 68, 78	TORQUE ROD BUSHING
1-51519-113-0	ISUZU	V-10	TORQUE ROD BUSHING
1-53215-002-2 RH	ISUZU	KB20	FRT.ENGINE MOUNTING
1-53215-039-0 / 056-0	ISUZU	V295, V-10	ENGINE MOUNTING FRONT
1-53215-048-0	ISUZU	6BB1 JCR, SBR, JCM	ENGINE MOUNTING FRONT
1-53215-048-0	ISUZU	JCM	Front Engine Mounting
1-53215-061-0	ISUZU	V330, V-12, JUMBO	ENGINE MOUNTING FRONT
1-53215-088-0	ISUZU	ROCKY175HP	Front Engine Mounting
1-53215-088-0	ISUZU	ROCKY 175, ROCKY 175HP	FRONT ENGINE MOUNTING
1-53215-108-0	ISUZU	V340, 10PD1	ENGINE MOUNTING FRONT
1-53215-141-0	ISUZU	TFR	FRT.ENGINE MOUNTING
1-53215-151-0	ISUZU	ROCKY 240HP	Front Engine Mountine
1-53215-151-0	ISUZU	ROCKY 240, ROCKY 240HP	FRONT ENGINE MOUNTING
1-53215-171-0	ISUZU	6SD1	ENGINE MOUNTING FRONT
1-53215-183-0	ISUZU	ROCKY 195HP	Front Engine Mounting
1-53215-183-0	ISUZU	ROCKY 195, ROCKY 195HP	FRONT ENGINE MOUNTING
1-53215-187-0	ISUZU	DECA	Front Engine Mounting
1-53215-187-0	ISUZU	DECA	FRONT ENGINE MOUNTING
1-53215-189-0 / 151-0	ISUZU	6QA1 SMALL	ENGINE MOUNTING FRONT
1-53215-195-0 / 134-0	ISUZU	6AQ1 BIG	ENGINE MOUNTING FRONT
1-53225-060-0	ISUZU	12PB1, V295, 6 1/2"	ENGINE MOUNTING REAR
1-53225-062	ISUZU	10PB1, V195, 5 1/2"	ENGINE MOUNTING REAR

1-53225-105-4	ISUZU	10PC1, GITNA	ENGINE MOUNTING REAR
1-53225-139-0	ISUZU	6BB1	ENGINE MOUNTING REAR
1-53225-187-1	ISUZU	10PC1 MATAAS	ENGINE MOUNTING REAR
1-53225-193-0	ISUZU	6BG1	ENGINE MOUNTING REAR
1-53225-225-0	ISUZU	6QA1	ENGINE MOUNTING REAR, RH
1-53225-226-0	ISUZU	6QA1	ENGINE MOUNTING REAR, LH
1-53225-236-1	ISUZU	6SD1 PANTAY	ENGINE MOUNTING REAR
1-53225-237-3	ISUZU	6SD1 LIHIS	ENGINE MOUNTING REAR
1-53225-241-0 / 242-0	ISUZU	10PD, 12PD	ENGINE MOUNTING REAR
1-53229-019-0	ISUZU	CXM	ENGINE STOPPER
1-53325-033-2	ISUZU	JCM,JCR	Rear Engine Mounting
1-53325-033-2	ISUZU	JCM, JCR	REAR ENGINE MOUNTING
1-53325-075-0	ISUZU	JCZ	Rear Engine Mounting
1-53325-075-0	ISUZU	JCZ	REAR ENGINE MOUNTING
1-53325-119-0 RH	ISUZU	JUMBO	Rear Engine Mounting
1-53325-119-0 RH	ISUZU	JUMBO	REAR ENGINE MOUNTING
1-53325-123-0 LH	ISUZU	JUMBO	REAR ENGINE MOUNTING
1-53325-123-0 LH	ISUZU	JUMBO	Rear Engine Mounting
1-53325-192-0	ISUZU	ROCKY 175HP	REAR ENGINE MOUNTING
1-53325-198-0	ISUZU	ROCKY 175 HP	Rear Engine Mounting
1-53325-276-0	ISUZU	ROCKY 195HP	Rear Engine Mounting
1-53325-276-0	ISUZU	ROCKY 195HP	REAR ENGINE MOUNTING
1-53366-045-0	ISUZU	JUMBO	Front Spring Bumper Lower
1-53366-045-0	ISUZU	JUMBO	REAR SPRING
1-53366-046-0	ISUZU	JUMBO	REAR SPRING
1-53366-122-0	ISUZU	FRR/6BG1	CAB SUPPORT LOWER
1-53419-314-0	ISUZU	FRR/6BG1	CAB SUPPORT UPPER
1-53459-231-0	ISUZU	VQR	CAB BUSHING
1-65600-216-0	ISUZU	CXM	CAB SUPPORT PAD
1-09333-045-0	ISUZU	JUMBO, JCM	BRAKE ADJUSTER HOLE PULG
1-09333-058-0	ISUZU	JCM	BRAKE ADJUSTER HOLE PULG
1-09333-059-0	ISUZU	JCM	BRAKE ADJUSTER HOLE PULG
2-22129-015-0	ISUZU	TRUCK (10MM)	EXHAUST PIPE SUPPORT
37521-J2100	ISUZU	JR2000	
3-94135-985-1	ISUZU	TROOPER 88	BASE MOTOR
3-94229-300-2	ISUZU	IZUSU LUV 72/80	BASE MOTOR
5-0820-SB2-962 (IREM8539)	ISUZU	I-MARK 1.5L W/TURBO 87-89	FRT.ENGINE MOUNTING
5-09800-039-0	ISUZU	TFR	PROPELLER SHAFT BEARING
5-31131-005-0	ISUZU	KBZ	BOOT CLUTCH RELEASE FORK

5-31131-009-0	ISUZU	KB20	BOOT BLUTCH RELEASE FORK
5-31413-002-1	ISUZU	KB20	PEDAL PAD BRAKE & CLUTCH
5-33619-045-0	ISUZU	KBZ	CHANGE LEVER COVER
5-33619-650-0	ISUZU	KB20	CHANGE LEVER COVER
5-37516-005-0	ISUZU	KS22, NPR (40MM) / NPR(40MM)	PROPELLER SHAFT BEARING
5-37516-006-1	ISUZU	ISUZU SUPER ELF250 (32MM)	PROPELLER SHAFT BEARING
5-37516-006-1	ISUZU	SUPER ELF (32MM)	Propeller Shaft
5-47169-002-0	ISUZU	KB20	BRAKE ADJUSTER HOLE PULG
5-47525-003-0	ISUZU	KB20	CYLINDER BRAKE BOOT
5-51151-001-0	ISUZU	ELF250	SPRING SHACKLE RUBBER.FRT
5-51151-005-1	ISUZU	ELF250	SPRING SHACKLE RUBBER.FRT
5-51151-012-0	ISUZU	ELF250	SPRING SHACKLE RUBBER.FRT
5-51151-013-0	ISUZU	ELF250	SPRING SHACKLE RUBBER.FRT
5-51174-001-0	ISUZU	KS21	FRONT SPRING BUMPER
5-51174-004-0	ISUZU	NPR	Front Spring Bumper
5-51174-004-0	ISUZU	ISUZU NKR	FRT.SPRING BUMPER
5-51351-007-0	ISUZU	ELF250	SPRING SHACKLE RUBBER,REAR
5-51351-009-0	ISUZU	ELF250	SPRING SHACKLE RUBBER,REAR
5-51351-028-0	ISUZU	SUPER ELF	SPRING SILENT BLOCK REAR
5-51351-029-0	ISUZU	SUPER ELF	SPRING SILENT BLOCK REAR
5-51351-033	ISUZU	NPR	SPRING BUSHING
5-51391-005-0	ISUZU	ELF250	REAR SPRING
5-53215-002-0	ISUZU	IZUSU 1600 72/80 LH	BASE MOTOR
5-53215-002-2	ISUZU	KB20-PICKUP	BAS/MOTOR.
5-53215-002-2	ISUZU	TROOPER 84-85, PICKUP 81-82, 83-85	ENGINE MOUNTING
5-53215-002-2	ISUZU	L. LUV G161/81	SOPORTE L. MOTOR
5-53215-002-2 RH	ISUZU	KB20	FRT.ENGINE MOUNTING
5-53215-003-0	ISUZU	IZUSU LUV 72/80 RH / 1600 72/80 RH	BASE MOTOR
5-53215-003-0	ISUZU	ISUZU/LUV 1600 (72/80) RH	ISUZU/LUV 1600 (72/80) RH
5-53215-003-2 LH	ISUZU	KB20	FRT.ENGINE MOUNTING
5-53215-058-0	ISUZU	TRUCK	FRT.ENGINE MOUNTING
5-53215-088-0	ISUZU	ROCKY 175HP	ENGINE MOUNTING
5-53231-004-0	ISUZU	KS21	CABIN MOUNTING
5-53325-010-0	ISUZU	KS ELF250	REAR ENGINE MOUNTING
5-53325-051-0	ISUZU	ISUZU NPR	REAR ENGINE MOUNTING
5-53325-150-0	ISUZU	NPR, KS22 / NPR	REAR ENGINE MOUNTING
5-53325-150-0A	ISUZU	TROOPER	Engine Mount
5-53325-150-0A	ISUZU	ISUZU TROOPER	ENGINE MOUNTING
5-53365-012-0	ISUZU	KS22	FRT.ENGINE MOUNTING

5-53366-007-0	ISUZU	ELF250	REAR SPRING
5-53366-008-0	ISUZU	KS21	REAR SPRING
5-53366-603-0	ISUZU	ELF250	FRT SPRING BUMPER
5-86203-136-0 (IRM7490)	ISUZU	OASIS LS 1996 L4 2.2 2156	ENGINE MOUNT FRONT
5-86203-136-0 (IRM7490)	ISUZU	OASIS S 1996 L4 2.2 2156	ENGINE MOUNT FRONT
5-86203-136-0 (IRM7490)	ISUZU	OASIS S 1997 L4 2.2 2254	ENGINE MOUNT FRONT
5-86203-136-0 (IRM7490)	ISUZU	OASIS 1998 L4 2.3 2234	ENGINE MOUNT FRONT
5-86203-136-0 (IRM7490)	ISUZU	OASIS 1999 L4 2.3 F23A7	ENGINE MOUNT FRONT
5-93215-002-0	ISUZU	KB FASTER	ENGINE MOUNTING FRONT, RH
5-93215-003-0	ISUZU	KB FASTER	ENGINE MOUNTING FRONT, LH
5-93225-269	ISUZU	R KB20	E/MOUNT
5-93225-269-0	ISUZU	KB20	REAR ENGINE MOUNTING
5-94226-012-0	ISUZU	TRUCK	BUMPER HOOD
5-94229-300-0	ISUZU	KBZ	REAR ENGINE MOUNTING
5-95552-966-0	ISUZU	TFR	BUMPER HOOD
8-02693-387-1	ISUZU	GEMINI	SUSPENSION BUSH
8-02875-013	ISUZU	KB20	LINK GROMMET
8-03468-771-1	ISUZU	KBZ	DOOR BUMPER RUBBER LOWER
8-08952-179-0	ISUZU	GEMINI	SUSPENSION BUSH
8-51631-014-0	ISUZU	GROMMET ELF ISU	SHOCK ABSORBER
8-51779-631-0	ISUZU	KB20	STABILIZER SHAFT RUBBER
8-53215-602	ISUZU	F KB20	E/MOUNT
8-79106-759-1	ISUZU	4BE1 NHR W/PIN	ENGINE MOUNTING FRONT, LH
8-91131-727-0	ISUZU	TFR2800 TURBO	Air Hose
8-91131-727-0	ISUZU	TFR2800 TURBO	AIR HOSE
8-94101-347-2	ISUZU	NPR, NKR	FRT.SPRING BUMPER
8-941-018-1 RH	ISUZU	NPR	Front Engine Mounting
8-94104-142-0	ISUZU	4x4	TOPE CHASIS DEL
8-94104-142-0	ISUZU	ISUZU TROOPER	BUMPER RUBBER
8-94104-142-0 RH	ISUZU	TROOPER	FRT.SPRING BUMPER LOWER
8-94104-143-0 LH	ISUZU	TROOPER	FRT.SPRING BUMPER LOWER
8-94111-903-0	ISUZU	4HF	ENGINE MOUNTING REAR
8-94111-903-0	ISUZU	4JB1 NKR	SOPORTE MOTOR TRAS
8-94113-313-2	ISUZU	NPR, NKR	SPRING SHACKLE RUBBER.REAR
8-94113-314-2	ISUZU	NPR, NKR	SPRING SHACKLE RUBBER.REAR
8-94113-323-2	ISUZU	NPR, NKR	SPRING SHACKLE RUBBER.REAR
8-94116-695-0	ISUZU	GEMINI	CHANGE LEVER COVER
8-94117-224-1 LH (IREM8438)	ISUZU	I-MARK 1.5L 85-89 MANUAL	TORQUE STRUTS FRONT
8-94117-838-1	ISUZU	NKR, NPR, NHR	PEDAL PAD

8-94118-510-3	ISUZU	NPR, NHK / NPR	REAR SPRING
8-94118-588-1	ISUZU	NPR	Spring Silent Block,Front
8-94119-958-1	ISUZU	NPR	Rear Spring Bumper
8-94119-958-1	ISUZU	NPR	REAR SPRING
8-94120021-0	ISUZU	NKR, CANTER (SHORT)	LEAF SPRING BUSHING COLLAR
8-94124-169-0	ISUZU	GEMINI	SUSPENSION BUSH
8-94124-170-0	ISUZU	GEMINI	SUSPENSION BUSH
8-94128-504-4	ISUZU	ISUZU	ENGINE MOUNTING
8-94130-354	ISUZU	NPR	SPRING BUSHING
8-94130-354-0	ISUZU	NPR, NHK	SPRING SILENT BLOCK.FRT
8-94135-985-1	ISUZU	PICKUP & TROOPER/KBZ / TROOPER(-86)	REAR ENGINE MOUNTING
8-94142-044-1	ISUZU	NHK	REAR SPRING
8-94146-523-1 (IREM8439)	ISUZU	I-MARK 1.5L 85-86 MANUAL / I-MARK 1.5L 87-89	TRANSMISSION MOUNT
8-94146-523-1 (IRM7080)	ISUZU	I-MARK 1985-89	ENGINE MOUNT
8-94146-523-2	ISUZU	1500CC	SUPPORT MOUNTING
8-94150-265-1	ISUZU	NKR, NHK	FRT.SPRING BUMPER
8-94150-265-2	ISUZU	NPR	Front Spring Bumper
8-94150-265-2	ISUZU	ISUZU NPR	FRT.SPRING BUMPER
8-94156-256	ISUZU	NPR	MUFFLER SUPPORT
8-94156-700-0	ISUZU	TFR	BOOT CLUTCH RELEASE FORK
8-94166-849-0	ISUZU	TROOPER	ENGINE MOUNTING
8-94166-849-2	ISUZU	TROOPER	ENGINE MOUNTING
8-94166-849-2 / 0 (IRM 7260)	ISUZU	TROOPER 2.2L, 2.3L 86-87	TRANSMISSION MOUNT
8-94171-274-1	ISUZU	TFR, NPR / NPR	SPRING SILENT BLOCK.FRT
8-94172-018-0	ISUZU	RH NPR NKR NHR	SOPORTE MOTOR RH CE80/90
8-94172-018-1	ISUZU	4BC NKR57	ENGINE MOUNTING FRONT, RH / BASE
8-94172-018-1	ISUZU	NPR 4BD1/4BD1T	SOPORTE MOTOR (R)
8-94172-018-1 RH	ISUZU	NPR 4BD 1/4BD1T	FRT.ENGINE MOUNTING
8-94172-019-0	ISUZU	CH NPR NKR NHR	SOPORTE MOTOR
8-94172-019-1	ISUZU	4BC NKR57	ENGINE MOUNTING FRONT, LH
8-94172-019-1	ISUZU	(L)ISUZ.NPR 4BD1/4BD1T	SOPORTE MOTOR (L)
8-94172-019-1 LH	ISUZU	NPR 4KD1/4BD1T	FRT.ENGINE MOUNTING
8-94173-374-0A RH	ISUZU	TFR2800CC	Front Spring Bumper Lower
8-94173-374-A RH	ISUZU	TFR97'	FRT.SPRING BUMPER LOWER
8-94173-375-0A LH	ISUZU	TFR2800CC	FRT.SPRING BUMPER LOWER
8-94173-375-0A LH	ISUZU	TFR2800CC	Rear Spring Bumper
8-94173-375-A LH	ISUZU	TFR97'	FRT.SPRING BUMPER LOWER
8-94174-885-1	ISUZU	1500CC	SUPPORT MOUNTING
8-94174-885-1 (IREM8442)	ISUZU	ISUZU I-MARK 1.5L 85-89	FRT.ENGINE MOUNTING

8-941772-019-1 LH	ISUZU	NPR	Front Engine Mounting
8-94177-240-0	ISUZU	ISUZU WFR- RH	
8-94177-240-1 RH	ISUZU	WFR (D)	Front Engine Mounting
8-94177-241-0	ISUZU	ISUZU WFR- LH	
8-94177-241-1 LH	ISUZU	WFR(D)	Front Engine Mounting
8-94177-241-1 LH	ISUZU	ISUZU WFR (D)	FRT.ENGINE MOUNTING
8-94200-740-0	ISUZU	KBD	OIL CAP
8-94202-430-0	ISUZU	ISUZU KB20	OIL CAP
8-94202-456-2	ISUZU	KB20	WASHER
8-94202-521-0	ISUZU	77/80	
8-94204-521-0	ISUZU	KB20 (OIL) KBD, KBZ	PROPELLER SHAFT BEARING (LONG)
8-94204-521-0	ISUZU	KB20, KBZ	PROPELLER SHAFT BEARING (SHORT)
8-94204-521-0	ISUZU	KBZ	Pro'Shaft Bearing
8-94206-750-0	ISUZU	GEMINI	STEERING BOOT
8-94207-168-0	ISUZU	GEMINI	BOOT CLUTCH RELEASE FORK
8-94207-180-0	ISUZU	KBZ	EXHAUST PIPE SUPPORT
8-94209-200-0	ISUZU	ISUZU GEMINI (P)	PROPELLER SHAFT BEARING
8-94209-200-0	ISUZU	GEMINI (P)	Pro'Shaft Cushion
8-94212-357-1	ISUZU	B161Z-GEMINI	BAS/MOTOR.
8-94212-357-1	ISUZU	GEMINI (P)	FRT.ENGINE MOUNTING
8-94212-746	ISUZU	GEMINI ISUZ	STABILIZER BUSHING
8-94213-168	ISUZU	KB26	SPRING BUSHING
8-94213-168-0	ISUZU	PICK UP KB 20	CAUC/MUELLE.KB20/2 6-P' UP/I
8-94213-295-0	ISUZU	GEMINI	SUSPENSION BUSH
8-94213-296-0	ISUZU	GEMINI(I>MARK)	BUJ/BZO/INF.
8-94213-296-0	ISUZU	GEMINI	SUSPENSION BUSH
8-94214-169-0	ISUZU	GEMINI	UPPER ARM BUSH
8-94217-683-1	ISUZU	KBZ	BUMPER HOOD
8-94218-504-4 LH	ISUZU	GEMINI (D)	Front Engine Mounting
8-94218-504-4 LH (IREM8621)	ISUZU	I-MARK 1.8L 81-84	FRT.ENGINE MOUNTING

8-94218-521-0	ISUZU	GEMINI (D)	PROPELLER SHAFT BEARING
8-94218-521-0	ISUZU	GEMINI (D)	Pro'Shaft Bearing
8-94220-807-0	ISUZU	GEMINI	REAR ENGINE MOUNTING
8-94220-817-0	ISUZU	GEMINI (D)	Rear Engine Mounting
8-94222-876-2	ISUZU	UBS	SOPORTE MOTOR
8-94223-107-0	ISUZU	ISUZU KBZ	STEERING COUPLING
8-94223-107-0	ISUZU	KBZ	Steering Coupling
8-94223-148-2	ISUZU	KBZ	Front Spring Bumper Lower
8-94223-157-0	ISUZU	KBZ	STABILIZER SHAFT RUBBER
8-94223165-2	ISUZU	ISUZU DECA	REAR SPRING
8-94223-165-2	ISUZU	ISUZU KBZ	REAR SPRING
8-94223-165-2	ISUZU	KBZ	Rear Spring Bumper
8-94223-166-2	ISUZU	KBZ	REAR SPRING
8-94223-167-2	ISUZU	KB21/26/41	SHACKLE KIT

8-94223-168-0	ISUZU	WFR LARGE	SPRING SHACKLE BUSHING
8-94223-168-0	ISUZU	ISUZU KBZ	SPRING SHACKLE RUBBER.FRT
8-94223-168-2	ISUZU	FASTER-Z	REAR SPRING
8-94223-366-0	ISUZU	KBZ, TROOPER	LOWER ARM BUSH
8-94223-674-3 RH	ISUZU	GEMINI (D)	FRT.ENGINE MOUNTING
8-94223-677-3 RH	ISUZU	GEMNI (D)	Front Engine Mounting
8-94223-699-0	ISUZU	KB21/6	STRUT BAR BUSHING
8-94225-048-2 RH	ISUZU	KBZ	Front Engine Mounting
8-94225-048-2 RH	ISUZU	KBZ	FRT.ENGINE MOUNTING
8-94225-049-2 LH	ISUZU	KBZ	Front Engine Mounting
8-94225-049-2 LH	ISUZU	ISUZU KBZ	FRT.ENGINE MOUNTING
8-94225-170-0	ISUZU	KBZ	BALL JOINT COVER UPPER
8-94225-171-0	ISUZU	KBZ	TIE ROD END COVER
8-94225-548-0	ISUZU	PICKUP/C223	BASE/MOTOR RH.
8-94225-548-2	ISUZU	KB26	SOPORTE MOTOR
8-94225-5482-A	ISUZU	C223	BASE C223 ISUZU
8-94225-549-2	ISUZU	PICKUP/C223	BASE/MOTOR LH.
8-94225-5492-A	ISUZU	C223	BASE C223 ISUZU
8-94225-963 (IRM7019)	ISUZU	SUV TROOPER 1984-87/ TRUCK, PICKUP 1986-87	ENGINE MOUNT
8-94225-963-2	ISUZU	UBS13-TROOPER	BAS/MOTOR/LH.
8-94225-963-2	ISUZU	UBS13-TROOPER	FRONT ENGINE MOUNTING
8-94225-963-2	ISUZU	L. 81/ 2000 - 1600	SOPORTE L. MOTOR
8-94225-963-2 (IRM7019)	ISUZU	SUV, TROOPER 1984-85/ TRUCK, PICKUP 1981-82	ENGINE MOUNT
8-94225-963-2 RH	ISUZU	TROOPER (P)	FRT.ENGINE MOUNTING
8-94225-964 (IRM7017)	ISUZU	TRUCK, PICKUP 1986-87	ENGINE MOUNT
8-94225-964-2	ISUZU	UBS13-TROOPER	BAS/MOTOR/RH.
8-94225-964-2	ISUZU	TROOPER 81/2000-1600	FRONT ENGINE MOUNTING, LH
8-94225-964-2	ISUZU	R. 81/ 2000 - 1600	SOPORTE R. MOTOR 600
8-94225-964-2 (IRM7017)	ISUZU	TRUCK, PICKUP 1983-87	ENGINE MOUNT
8-94225-964-2 LH	ISUZU	TROOPER / TROOPER(P)	Front Engine Mounting
8-94226-549-2	ISUZU	KB27	SOPORTE MOTOR
8-94226-557	ISUZU	KB26	ARM BUSHING UPPER
8-94226-557-2	ISUZU	KBD21/26/41-P'	BUJ/BZO/SUP.
8-94226-557-2	ISUZU	ISUZU KBZ, TROOPER	UPPER ARM BUSH
8-94226-557-2	ISUZU	KBZ,TROOPER	Upper Arm Bush
8-94226-805-0	ISUZU	BUDDY, WFR	SPRING SHACKLE RUBBER,REAR
8-94226-970-0	ISUZU	BUDDY	Front Spring Bumper Lower

8-94227-061-0	ISUZU	ISUZU TROOPER	STABILIZER SHAFT RUBBER
8-94229-300	ISUZU	R FASTER	E/MOUNT
8-94229-300-0	ISUZU	KB20 81-86	BASE/TRANS.
8-94229-300-0 (8-94135-985-1)	ISUZU	KBZ	REAR ENGINE MOUNTING
8-94229-300-0 / 8-94135-985-1	ISUZU	KBZ	Rear Engine Mounting
8-94229-300-2	ISUZU	C223-4CYLDSL/FAS	BAS/TRANS.
8-94229-300-2	ISUZU	G161Z KB KC / B/C 72/80 / LUV 1600(72/90)	ENGINE MOUNTING REAR
8-94234-319	ISUZU	KB26	SPRING BUSHING
8-94234-319-0	ISUZU	WFR SMALL	SPRING SHACKLE BUSHING
8-94234-319-0	ISUZU	KBZ, TROOPER	SPRING SHACKLE RUBBER REAR
8-94235-155-1	ISUZU	TFR	CABIN MOUNTING (FULL SET)
8-94237-365	ISUZU	KB PIN RELAY LEVER 8-94237-365	
8-94237-396-0	ISUZU	KBZ	FRT.SPRING BUMPER UPPER
8-94243-013	ISUZU	RH TROOPER UBS52 ISU	E/MOUNT
8-94243-013-2 RH	ISUZU	TROOPER (D)	Front Engine Mounting
8-94243-014	ISUZU	LH TROOPER UBS52 ISU	E/MOUNT
8-94243-014-2 LH	ISUZU	TROOPER(D)	Front Engine Mounting
8-94243-014-2 LH (IREM8048)	ISUZU	TROOPER II 2.2L 84-86	FRT.ENGINE MOUNTING
8-94246-748-0	ISUZU	KBZ	BALL JOINT COVER LOWER
8-94246-988-0	ISUZU	GEMINI (D)	PROPELLER SHAFT BEARING
8-94246-988-0	ISUZU	GEMINI (D)	Pro'Shaft Cushion
8-94249427-0	ISUZU	NKR, CANTER (LONG)	LEAF SPRING BUSHING COLLAR
8-94259-086-A	ISUZU	TFR	FRT.SPRING BUMPER UPPER
8-94310-384-0 LH	ISUZU	TROOPER2800CC	Cabin Mounting
8-94310-384-0 LH	ISUZU	ISUZU TROOPER2800CC	CABIN MOUNTING BIG
8-94310-384-0 LH (BIG)	ISUZU	TROOPER2800CC	Cabin Mounting
8-94312-678-0	ISUZU	RODIO 4WD	DRIVE SHAFT BOOT OUTER
8-94312-680-0	ISUZU	ISUZU RODIO 4WD	DRIVE SHAFT BOOT INNER
8-94316-903-0	ISUZU	TFR	CABIN MOUNTING
8-94320-727-0	ISUZU	ISUZU TFR	AIR HOSE
8-94320-727-0	ISUZU	TFR	Air Hose
8-94322-658-1 LH	ISUZU	TROOPER2800CC	Cabin Mounting
8-94322-658-1 LH	ISUZU	TROOPER2800CC	CABIN MOUNTING SMALL
8-94322-658-1 LH (SMALL)	ISUZU	TROOPER2800CC	Cabin Mounting
8-94325-159-0 RH	ISUZU	ISUZU TROOPER2800CC	CABIN MOUNTING
8-94325-159-0 RH	ISUZU	TROOPER2800CC	Cabin Mounting
8-94325-160-0 RH	ISUZU	TROOPER2800CC	Cabin Monting
8-94325-160-0 RH	ISUZU	ISUZU TROOPER2800CC	CABIN MOUNTING

8-94325-597-2 (IREM8576)	ISUZU	AMIGO 4WD 2.3L 89-93	FRT.ENGINE MOUNTING LH
8-94325-597-2 (IREM8576)	ISUZU	ISUZU AMIGO 4WD 2.6L 89-94	FRT.ENGINE MOUNTING LH&RH
8-94325-597-2 (IRM7081)	ISUZU	SUV AMIGO 1989-94	ENGINE MOUNT
8-94328-799-0	ISUZU	TFR, RODEO / TFR ROMIO / LUV 2300 (88-)	PROPELLER SHAFT BEARING
8-94328-799-0	ISUZU	LUV 2300 TROOPER 2000	
8-94328-800-0	ISUZU	TFR	PROPELLER SHAFT BEARING
8-94334-158-0	ISUZU	PICKUP/4JA1	BASE/MOTOR RH.
8-94334-159-0	ISUZU	PICKUP/4JA1	BASE/MOTOR LH.
8-94337-947-2 (IRM7491)	ISUZU	TROOPER 1989-1990 V6 2.8 2827	ENGINE MOUNT LEFT FRONT
8-94337-947-2 (IRM7491)	ISUZU	TROOPER 1991 V6 2.8	ENGINE MOUNT LEFT FRONT
8-94363-547-0	ISUZU	ISUZU ASKA	DRIVE SHAFT BOOT OUTER
8-94375-282-5 (IRM7075)	ISUZU	SUV TROOPER 1994-95	ENGINE MOUNT
8-94375-282-5 RH	ISUZU	TROOPER92-95'	Front Engine Mounting
8-94375-283-2	ISUZU	RODEO & TROOPER	ENGINE MOUNTING
8-94375-283-5 / 8-94375-283-2	ISUZU	RODEO 4WD 96-97	ENGINE MOUNTING LH
8-94375-283-5 LH	ISUZU	TROOPER92-95'	Front Engine Mounting
8-94375-283-5 LH (IRM7105)	ISUZU	TROOPER92-95'	FRT.ENGINE MOUNTING
8-94375-284-0	ISUZU	PICKUP & RODEO	ENGINE MOUNTING
8-94375-285-0	ISUZU	PICKUP & RODEO	ENGINE MOUNTING
8-94375-288-1	ISUZU	RODEO & TROOPER	ENGINE MOUNTING
8-94380-614-0	ISUZU	TFR	CABIN MOUNTING
8-94386-481-1	ISUZU	TROOPER 92-95'	REAR ENGINE MOUNTING
8-94386-486-1	ISUZU	TROOPER92-95'	REAR ENGINE MOUNTING
8-94404-859-0 LH (IREM8577)	ISUZU	PICKUP 2WD 2.2L DIESEL 87	FRT.ENGINE MOUNTING
8-94408-840-2	ISUZU	TROOPER	BUJ/BZO/SUSP.
8-94408-840-2	ISUZU	TFR, TROOPER	UPPER ARM BUSH
8-94408-841-1	ISUZU	LUV 2300 4X4	BUSHING
8-94408-841-1	ISUZU	RODED 4WD	Lower Arm Bush (Small)
8-94408-841-1	ISUZU	RODEO 4WD	LOWER ARM BUSH (SMALL)
8-94408-842-2 / 1	ISUZU	LUV 2300 4X4	SPRING SHACKLE RUBBER
8-94414-393-0	ISUZU	TROOPER 2000 RH	BASE MOTOR
8-94414-393-0 (IRM7019)	ISUZU	SUV, TROOPER 1986-87/ TRUCK, PICKUP 1983-87	ENGINE MOUNT
8-94414-393-0 RH	ISUZU	TROOP.2000/2300 (-86)	

8-94414-393-0 RH (IREM8054)	ISUZU	PICKUP 2WD 1.8L, 1.9L, 2.3L 81-87 / TROOPER II 1.9L 84- 85 / TROOPER II 2.3L	FRT.ENGINE MOUNTING
8-94414-394-0	ISUZU	TROOPER 2000 LH	BASE MOTOR
8-94414-394-0 (IRM7017)	ISUZU	SUV, TROOPER 1984- 85 /TRUCK, PICKUP 1981-82	ENGINE MOUNT
8-94414-394-0 LH	ISUZU	TROOP.2000/2300 (- 86)	
8-94414-394-0 LH (IREM8053)	ISUZU	PICKUP 2WD 1.8L 81- 85 / PICKUP 2WD 2.3L 86-87 / TROOPER II 1.9L, 2.3L 84-85	FRT.ENGINE MOUNTING
8-94422-867-0	ISUZU	PICKUP 4CYL 88-89, TROOPER 87	ENGINE MOUNTING
8-94422-867-2 (IRM6976)	ISUZU	SUV, ,TROOPER 1986- 87 /TRUCK, PICKUP 1990-94 / SUV,AMIGO 1989-93, PICKUP 1988-98	ENGINE MOUNT
8-94422-868-2	ISUZU	AMIGO	ENGINE MOUNTING
8-94422-868-2	ISUZU	UBS	SOPORTE MOTOR
8-94425-963-2 RH	ISUZU	TROOPER	Front Engine Mounting
8-94429-300-2 (IRM7081)	ISUZU	SUV, AMIGO 1989-93	TRANSMISSION MOUNT
8-94433-672-0	ISUZU	TFR	BUSHING
8-94433-672-0	ISUZU	ISUZU TFR	TENSION ROD BUSH SET
8-94433-673-0	ISUZU	TFR	Front Spring Bumper Lower
8-94434-208-1	ISUZU	AMIGO 89-93	ENGINE MOUNTING
8-94441-572-1	ISUZU	AMIGO & PICKUP& RODEO&TROOPER	ENGINE MOUNTING
8-94457-519-0 (IREM8257)	ISUZU	RODEO 4WD 3.1L 91- 92 AUTO / TROOPER II 2.6L 88-91 MANUAL	TRANSMISSION MOUNT
8-94458-383-2	ISUZU	TROOPER 2.6L 88-91 MTM	ENGINE MOUNT
8-94458-383-2	ISUZU	RODEO	ENGINE MOUNTING
8-94459-452-1	ISUZU	TFR	REAR SPRING
8-94459-459-1	ISUZU	TFR	STABILIZER SHAFT RUBBER
8-94460-092-0	ISUZU	CAUCHO PICKUP	CAUCHO BAL./CENTRO PICKUP
8-94472-679-0	ISUZU	TFR	EXHAUST PIPE SUPPORT
8-94472-973-0	ISUZU	TROOPER	Engine Mount
8-94472-973-0	ISUZU	TFR	REAR ENGINE MOUNTING
8-94472-973-0	ISUZU	TROOPER 87	TRANSMISSION MOUNT
8-94482-050	ISUZU	TROOPER	BASE RH

8-94482-060	ISUZU	TROOPER	BASE LH
8-94482-405-0 RH	ISUZU	TFR(4WD)	Front Engine Mounting
8-94482-405-0 RH	ISUZU	ISUZU TFR (4WD)	FRT.ENGINE MOUNTING
8-94482-406-0	ISUZU	TFR(4X4)-FASTER/	BAS/MOTOR.
8-94482-406-0	ISUZU	TFR (4WD)	FRT.ENGINE MOUNTING LH
8-94482-406-0	ISUZU	LUV 2300cc. Y TROOPER	SOPORTE MOTOR
8-94482-406-0 LH	ISUZU	TFR(4WD)	Front Engine Mounting
8-94482-406-0 LH	ISUZU	TFR (4WD)	FRT.ENGINE MOUNTING
8-94482-407-0 RH	ISUZU	TFR	Front Engine Mounting
8-94482-408-0 LH	ISUZU	TFR	Front Engine Mounting
8-94482-408-0 LH	ISUZU	TFR	FRT.ENGINE MOUNTING
8-970-080-621-0 LH	ISUZU	NKR(4JB1)	Front Engine Mounting
8-97018-166-0	ISUZU	TROOPER	Lower Arm Bush
8-97018-166-0	ISUZU	ISUZU RODEO 4WD, TROOPER	LOWER ARM BUSH (BIG)
8-97018-166-0	ISUZU	RODEO 4WD	Lower Arm Bush (BIG)
8-97018-227-2	ISUZU	TROOPER	Link Rod Assy Front
8-97018-227-2	ISUZU	TROOPER	LINK ROD ASSY FRONT
8-97018-228-2	ISUZU	TROOPER	Link Rod Assy Front
8-97018-228-2	ISUZU	ISUZU TROOPER	LINK ROD ASSY FRONT
8-97020-607-0	ISUZU	PICKUP	ENGINE MOUNTING
8-97023-183-0	ISUZU	ISUZU TFR	EXHAUST PIPE SUPPORT
8-97025-752-0	ISUZU	RODEO, TROOPER92-95'	PROPELLER SHAFT BEARING
8-97028-752-0	ISUZU	TROOPER92-95'	Propeller Shaft
8-97029579-0	ISUZU	INTECO 4JB1	ENGINE MOUNTING FRONT, RH
8-97029579-0 LH	ISUZU	PANTHER	ENGINE MOUNTING
8-97029580-0	ISUZU	INTECO 4JB1	ENGINE MOUNTING FRONT, LH
8-97029580-0 RH	ISUZU	PANTHER	ENGINE MOUNTING
8-97039-196-5	ISUZU	TROOPER	REAR ENGINE MOUNTING
8-97039-196-6	ISUZU	TROOPER	Rear Engine Mounting
8-97066-800-0 (IREM8579)	ISUZU	AMIGO 2WD 2.3L 89-93	FRT.ENGINE MOUNTING
8-97066-800-0 (IREM8579)	ISUZU	AMIGO 4WD 2.3L 89-93	FRT.ENGINE MOUNTING RH
8-97066-800-0 RH	ISUZU	TROOPER 2300 88-405-0	
8-97066-990-0 LH	ISUZU	TROOPER 2300 88-406-0	
8-97073-377-2	ISUZU	4HF-1	ENGINE MOUNTING FRONT, RH
8-97073-378-2	ISUZU	4HF-1	ENGINE MOUNTING FRONT, LH
8-97079-219-1	ISUZU	NPR 96	E/MOUNT RIGHT
8-97079-219-1 RH	ISUZU	NHRP120HP / KHR 120HP, NHR 120HP	Front Engine Mounting
8-97079-220-1	ISUZU	NPR 96	E/MOUNT LEFT
8-97079-220-1 LH	ISUZU	NHR120HP	Front Engine Mounting
8-97079-220-1 LH	ISUZU	ISUZU KHR 120HP, NHR 120 HP	FRT.ENGINE MOUNTING
8-97080 620-0 RH	ISUZU	NKR(4JB1)	Front Engine Mounting

8-97080-620-0	ISUZU	NKR 110HP (4JB1)	FRT.ENGINE MOUNTING
8-97080-620-0	ISUZU	NKR 4JB1	SOPORTE MOTOR DEL(R)
8-97080-620-0 RH	ISUZU	ISUZU NKR 110HP (4JB1)	FRT.ENGINE MOUNTING
8-97080-621-0	ISUZU	NKR 4JB1	SOPORTE MOTOR DEL(L)
8-97080-621-0	ISUZU	NKR 110HP (4JB1)	ENGINE MOUNTING
8-97080-621-0 LH	ISUZU	ISUZU NKR 110HP (4JB1)	FRT.ENGINE MOUNTING
8-97080-621-1 LH	ISUZU	NKR (4JB1)	ENGINE MOUNTING
8-97085-122-0	ISUZU	(R) NKR 4JB1	ENGINE MOUNTING RR.
8-97085-122-0	ISUZU	NKR 4JB1	SOPORTE MOTOR DEL(R)
8-97085-123-0	ISUZU	(L) NKR 4JB1	ENGINE MOUNTING
8-97085-123-0	ISUZU	NKR 4JB1	SOPORTE MOTOR DEL(L)
8-97092068-0	ISUZU	NKR L110 HP	(RH) FRONT ENGINE MOUNTING
8-97092-068-0 RH	ISUZU	NKR 110 HP (4BE1)	Front Engine Mounting
8-97092-069-0 LH	ISUZU	NKR 110HP(1BE1) / NKR 110HP (4BE1)	Front Engine Mounting
8-97104-157-1 (IRM7071)	ISUZU	SUV, TROOPER 1994-99,VEHICROSS 1999	ENGINE MOUNT
8-97104-157-1 RH	ISUZU	TROOPER96-98'	Front Engine Mounting
8-97104-157-1 RH (IREM8451, IRM7071)	ISUZU	TROOPER96-98'	FRT.ENGINE MOUNTING
8-97104-158-1 LH	ISUZU	TROOPER96-98'	Front Engine Mounting
8-97104-158-1 LH (IREM8351, IRM7072)	ISUZU	RODEO 4WD 3.2L 95-97 / TROOPER 3.2L 96-98	FRT.ENGINE MOUNTING
8-97104-158-2 (IRM7072)	ISUZU	SUV TROOPER 1995-99	ENGINE MOUNT
8-97104-268-0 RH (IREM8352)	ISUZU	RODEO 2WD 2.6L 95-97 / RODEO 4WD 3.2L 95-97	FRT.ENGINE MOUNTING
8-97105-269-1 LH (IREM8499)	ISUZU	RODEO 2WD 2.6L 95-97	FRT.ENGINE MOUNTING
8-97106-758 RH	ISUZU	NHR	Front Engine Mounting
8-97106-758-0 RH	ISUZU	NHR, NHK	FRT.ENGINE MOUNTING
8-97106-758-1	ISUZU	4BE1 NHR W/PIN	ENGINE MOUNTING FRONT, RH
8-97106-759-0 LH	ISUZU	NHR120 HP	Front Engine Mounting
8-97106-759-0 LH	ISUZU	ISUZU NHR, NHK	FRT.ENGINE MOUNTING
8-97120-497-1 RH	ISUZU	N Q R	ENGINE MOUNTING
8-97120-498-1 LH	ISUZU	N Q R	ENGINE MOUNTING
8-97133-866-0	ISUZU	TROOPER96-98' (ATM)	REAR ENGINE MOUNTING
8-97133-866-0	ISUZU	TROOPER 98-99	TRANSMISSION MOUNT
8-97138-980-0	ISUZU	TFR97' 4WD	DRIVE SHAFT BOOT INNER
8-97138-981-0	ISUZU	ISUZU TFR97' 4WD	DRIVE SHAFT BOOT OUTER

8-97177-241-1 LH	ISUZU	WFR (D)	ENGINE MOUNTING
8-97910-966-0 RH	ISUZU	TFR2800 TURBO / TFR2800CC TURBO	Front Engine Mounting
8-97910-967-0 LH	ISUZU	TFR2800 TURBO / TFR2800CC TURBO	Front Engine Mounting
8-97911-266-0	ISUZU	ISUZU TFR2800 TURBO	REAR ENGINE MOUNTING
8-97911-268-0	ISUZU	TFR (2800)	Rear Engine Mounting
8-97911-268-0	ISUZU	TFR2800CC TURBO	REAR ENGINE MOUNTING
90385-16007	ISUZU	C240 16X25X19	SHOCK ABSORBER BUSHING
90385-19003	ISUZU	ELF 19X30X21	SHOCK ABSORBER BUSHING
90385-22026	ISUZU	FORWARD 22X32X25	SHOCK ABSORBER BUSHING
9-09756-034-0	ISUZU	KS21	BRAKE ADJUSTER HOLE PULG
9-11349-134-0	ISUZU	KS21	BOOT CLUTCH RELEASE FORK
9-11750-038-0	ISUZU	TRUCK, KB20 / KB20	OIL CAP
9-11750-038-1	ISUZU	KB20	OIL CAP
9-15339-019-0	ISUZU	TRUCK	
9-23241-003-0	ISUZU	TRUCK	PEDAL PAD ACCELERATOR
9-23319-039-0	ISUZU	TRUCK	
9-31131-034-0	ISUZU	ELF250	BOOT CLUTCH RELEASE FORK
9-31131-035-0	ISUZU	ELF250	BOOT CLUTCH RELEASE FORK
9-31131-602-0	ISUZU	KS21	BOOT CLUTCH RELEASE FORK
9-31413-002-0	ISUZU	ELF250	PEDAL PAD BRAKE & CLUTCH
9-33614-047-0	ISUZU	BUS 260HP	CHANGE LEVER COVER
9-33669-649-0	ISUZU	KS21	CHANGE LEVER COVER
9-36189-008-0	ISUZU	TRUCK	REAR ENGINE MOUNTING
9-37516-006-1	ISUZU	JCM (45MM), W/SEAL / JCM(45MM)	PROPELLER SHAFT BEARING
9-37516-008-0	ISUZU	TD, TMK, DH100	CENTER BEARING CUSHION
9-37516-008-0	ISUZU	BUS 260HP	PROPELLER SHAFT BEARING
9-37516-030-0	ISUZU	TRUCK KS21 ELF250	PROPELLER SHAFT BEARING
9-37516-045-0	ISUZU	SPM, E-120	CENTER BEARING CUSHION
9-37516-045-1	ISUZU	FXZ (6311) (260CC), BUS 260HP / FXZ (260CC)	PROPELLER SHAFT BEARING
9-39510-093-0	ISUZU	D-500	CENTER BEARING CUSHION
9-44135-607	ISUZU	KB COUPLING	
9-47169-046-1	ISUZU	ISUZU KB20	BRAKE ADJUSTER HOLE PULG
9-47313-009-0	ISUZU	TRUCK	PEDAL PAD BRAKE & CLUTCH
9-47313-015-0	ISUZU	BUS	PEDAL PAD BRAKE & CLUTCH
9-51151-023-0	ISUZU	16X36X68	LEAF SPRING BUSHING
9-51151-023-0	ISUZU	ELF221	SPRING SILENT BLOCK, FRT

9-51151-029-0	ISUZU	16X42X80	LEAF SPRING BUSHING
9-51217-052-0	ISUZU	KB20	Front Spring Bumper Upper
9-51217-612-1	ISUZU	KB20	Front Spring Bumper Lower
9-51241-609-1 / SK-5081	ISUZU	KB20/25/40 ISUZU	SHAFT KIT
9-51266-048-0	ISUZU	KB20	Lower Arm Bush
9-51266-048-0	ISUZU	KB20	LOWER ARM BUSH
9-51351-029-0	ISUZU	ELF221	SPRING SILENT BLOCK REAR
9-51391-626-1	ISUZU	KB20	REAR SPRING
9-51391-6261-1	ISUZU	KB20	Rear Spring Bush Set
9-51519-057-0	ISUZU	ISUZU 74X121X48	SUSPENSION BUSHING
9-51613-619-0	ISUZU	TROOPER	TENSION ROD BUSH
9-51631-026-0	ISUZU	TD, V-10 26X40X28	SHOCK ABSORBER BUSHING
9-51631-029-0	ISUZU	BUS TYPE 30X50X34	SHOCK ABSORBER BUSHING
9-51631-050-0	ISUZU	TRUCK	SHOCK ABSORBER GROMMET
9-53215-031-0 RH	ISUZU	KS22	Front Engine Mounting
9-53215-032-0 LH	ISUZU	KS22	Front Engine Mounting
9-53215-058-0	ISUZU	TRUCK	Front Engine Mounting
9-53215-058-0	ISUZU	TRUCK	FRT.ENGINE MOUNTING
9-53215-058-0 / -179-0	ISUZU	DA640	ENGINE MOUNTING FRONT
9-53215-088-0	ISUZU	TRUCK 150HP	FRT.ENGINE MOUNTING
9-53215-116-0	ISUZU	BUS200HP	Front Engine Mounting
9-53215-116-0	ISUZU	TRUCK 200HP, BUS 200HP	FRT.ENGINE MOUNTING
9-53215-177-0	ISUZU	TMK, E-120	ENGINE MOUNTING FRONT
9-53215-197-0	ISUZU	D500	ENGINE MOUNTING FRONT
9-53215-602-0	ISUZU	C240 ELF250	ENGINE MOUNTING FRONT
9-53215-602-0	ISUZU	ELF250	Front Engine Mounting
9-53215-602-0	ISUZU	C-190	SOPORTE MOTOR
9-53215-611-0	ISUZU	C-240	SOPORTE MOTOR
9-53215-611-2	ISUZU	4BA1 ELF350	ENGINE MOUNTING FRONT, RH
9-53215-611-2 RH	ISUZU	KS21	Front Engine Mounting
9-53215-611-2 RH	ISUZU	ISUZU KS21	FRT.ENGINE MOUNTING
9-53215-612-0	ISUZU	C-240	SOPORTE MOTOR
9-53215-612-0 LH	ISUZU	KS21	ENGINE MOUNTING
9-53215-612-2	ISUZU	4BA1 ELF350	ENGINE MOUNTING FRONT, LH
9-53215-612-2 LH	ISUZU	KS21	Front Engine Mounting
9-53225-607-0	ISUZU	KS21	REAR ENGINE MOUNTING
9-53325-216-0	ISUZU	ISUZU TRUCK	REAR ENGINE MOUNTING
9-53325-216-0	ISUZU	TRUCK	Rear Engine Mounting
9-53325-607-0	ISUZU	KS21	REAR ENGINE MOUNTING
9-53366-122-0	ISUZU	TD, TMK	SPRING CUSHION RR.
9-54115-046-0	ISUZU	ISUZU KB20	BUMPER HOOD

9-54226-020-0	ISUZU	TRUCK	BUMPER HOOD
9-94104-142-0 RH	ISUZU	GEMINI	Front Spring Bumper Lower
9-94104-143-0 LH	ISUZU	GEMINI	Front Spring Bumper Lower
9-94104-143-0 LH	ISUZU	GEMINI	FRT.SPRING BUMPER LOWER
9-94220-817-0	ISUZU	ISUZU GEMINI	ENGINE MOUNTING
9-94375-282-0 RH	ISUZU	TROOPER1997'	ENGINE MOUNTING
9-94375-282-5 RH	ISUZU	TROOPER97'	Front Engine Mounting
9-94375-282-5 RH	ISUZU	TROOPER JEEP97'	FRT.ENGINE MOUNTING
9-94375-283-0 LH	ISUZU	TROOPER1997'	ENGINE MOUNTING
9-94375-283-5 LH	ISUZU	TROOPER97'	Front Engine Mounting
9-94375-283-5 LH	ISUZU	ISUZU TROOPER JEEP97'	FRT.ENGINE MOUNTING